



PENLIGHT

T10-1001



User Manual

⚠ WARNINGS

- Please read user manual carefully before using the light.
- Product will generate heat while working, please be cautious with that to avoid any possible harm.
- Do not shine light directly into eyes.
- Keep the light away from children.
- Don't throw the product into fire.
- This product is not meant for usage underwater.

Operation

- ① ON/OFF: When the light is off, single click on the switch to turn on the flashlight, click again to turn it off.
- ② Output selections: when the light is on, Lightly press the switch to swap Low-Mid-High.

FAQs

Problems	Causes	Solutions
Abnormal flash or failure to turn on	Check if the switch is turned on correctly	Turn on the switch
	Check if it is properly closed	Re-open & properly close assembly again
	Check if the battery has power	Use the charger to check the battery
	Check if the battery is reversed	Remove the battery and reassemble it correctly
Abnormal noise	Check if the conductive position is dirty	Clean the surface with alcohol
	Check if foreign matter falls in the tube	Pour out possible foreign matter

If problems still persist, please contact customer service at:

Email: customerservice@northskysupply.com

Phone: 800-805-6686

Warranty policy

1 Year Limited Warranty: We guarantee this product to be free from defects in materials and workmanship for a period of one (1) year after delivery.

